



INSTRUCTIONS

1. Stretch out the pool noodles so that it makes a U shape.
2. Attach the Mesh to the screw clamps
 - a. If you need more tension, you can fold the mesh so that its tighter
 - b. Unfold mesh and make wider, if you want less tension so your body sinks more into the water while floating
3. Attach the phone pouch using the ball-bungee cords around the noodles
4. Attach the phone bluetooth speaker using the ball-bungee cords around the noodles

WARNING

- This is not a lifesaving device.
- Use only under adult supervision.
- Not intended for children without supervision.
- Do not use it in open water, currents, waves, or deep water without swimming ability.
- Inspect before each use.
- Not intended for children under 13.
- Use only in shallow, calm pool water.
- Do not use it as a flotation safety device.