



INSTRUCTIONS

1. Stretch out the pool noodles so the 2 long pieces are about 2 feet apart, horizontally.
2. Attach the corner that has the latches
3. Place the mesh into the screw clamps and tighten each
 - a. If you need more tension, you can fold the mesh so that its tighter
 - b. Unfold mesh and make wider, if you want less tension so your body sinks more into the water while floating
4. Attach the phone pouch using the ball-bungee cords around the noodles
5. Attach the phone bluetooth speaker using the ball-bungee cords around the noodles
6. Attach the head rest to one of the shorter noodles using a ball-bungee cord
7. If you need the internal core bungee tension tighter or looser, you can always adjust the screw clamps at the corners too.

WARNING

- This is not a lifesaving device.
- Use only under adult supervision.
- Not intended for children without supervision.
- Do not use it in open water, currents, waves, or deep water without swimming ability.
- Inspect before each use.
- Not intended for children under 13.
- Use only in shallow, calm pool water.
- Do not use it as a flotation safety device.